



VPEG eVib Software Download Quick Reference

2-page field reference for PC + Android setup

Install only the software needed to operate and support the VPEG eVibs.

1. Download the main PC installer

Seismic Source Downloads:

<https://seismicsource.com/html/downloads>


- Download the Windows Software Installer .EXE from the Seismic Source downloads page.
- Run the installer, then open Seismic Source Installer from the PC.
- Select INSTALL PRODUCTS to open the software list.
- Choose the required VPEG programs below, then select Install Products.

Required Downloads for VPEG eVibs

Installer Category	Program	Use
Android	NavLink VPEG	Primary Android app used to control the VPEG in the field.
Android	SSCApPStore	Android installer/updater. Shows available updates for the NavLink VPEG app.

Android install note: NavLink VPEG and SSCAppStore download as .APK files that must be installed on the Android tablet/device.

Visual reference – Main Installer



After opening the installer, select **INSTALL PRODUCTS**.

Visual reference - Android Downloads



Under **Android**, select **NavLink VPEG** and **SSCApPStore**.


2. Optional / support downloads

Installer Category	Program	Used For
Force 3, BB3, RTM3	Source Signature	View signals recorded to USB True Reference, internal accelerometer, and near geophone if connected.
Force 3, BB3, RTM3 > Legacy	Source Control F3	Edit or customize the VPEG sweep table #1-16.
GPS	NavLink	PC/laptop field control option when not using an Android tablet.
Force 3, BB3, RTM3	SourceLink	PC project setup and file workflow for node users. Used for maps, node locations, VP locations, project files, and end-of-day processing imports.

Quick install checklist


- Confirm the PC is online before checking for updates or installing products.
- For Android field operation, install NavLink VPEG and SSCAppStore on the tablet.
- For node-based surveys, install SourceLink on the PC used for project setup and file handling.
- **Android Tablet** recommended for field operation

Visual reference - Force 3 / optional tools



Select Source Signature, SourceLink, or Source Control F3 only as needed.

Visual reference - GPS / PC NavLink



Under GPS, select NavLink when using a PC/laptop instead of Android control.